


Place SAM 01 profile block on side spindle 2.  
 Place SAM 01 profile block on side spindle 3.  
 Place Angle B profile block on the first top spindle, to produce Chamfer.

Please tick in box - Is groove a visible top surface for priming YES  NO



CUSTOMER TO CONFIRM DIMENSIONS A+B+C INCLUDING PRODUCT WIDTH AND THICKNESS.  
 WHEN DIMENSION C=0, ANGLED CUTTER MUST BE SET ON SIDE HEAD!

PRINTED COPY UNCONTROLLED

AREA MACHINED AWAY: AxC SQMM

MOULDER	3,4,5,6,7
PASSES	1
REV:	1
AUTH:	
TOLERANCE	+/- 0.5MM



Newpark Industrial Estate  
 Greystone Road, Antrim  
 BT41 2RU  
 T: +44 (0)28 9442 8288 F: +44 (0)28 9442 8244  
 E: team@samonline.co.uk  
 W: www.samonline.co.uk

PROFILE	DRAWN BY	S McMaster	REV: 1
SP 601	DATE	18/06/2019	AUTH:
	SCALE	1:1	TOLERANCE +/- 0.5MM